

MPDU User Manual

Contents

2	SCOPE OF APPLICATION	4
3	TERMS & DEFINITIONS	4
4	MAIN FUNCTIONS AND INSTALLATION	6
4.1	Function description	6
4.2	Product picture and description	7
4.3	Installation	11
5	HARDWARE INSTRUCTION.....	12
5.1	MPDU module.....	12
5.2	System initialization	12
5.3	Hardware Settings.....	15
5.4	Daisy-Chain	15
5.5	RJ45 terminal PIN instruction of RS485 port.....	17
5.6	Sensor Box (Optional)	18
6	MPDU SOFTWARE INTRODUCTION	18
6.1	Software overview	18
6.2	Access method	18
6.2.1	Web interface	19
6.2.2	SNMP access	35
6.2.3	Telnet Command Line Interface	35
6.2.4	MODBUS-RTU access	41
7	FREQUENTLY ASKED QUESTIONS (FAQS)	41
7.1	Q: FORGET IP ADDRESS?	41
7.2	Q: FAILED TO LOGIN?	41
7.3	Q: FAIL TO SEND EMAIL NOTIFICATION?	41
7.4	Q: HOW TO RESTORE TO FACTORY SETTINGS?	41
8	TECHNICAL PARAMETERS.....	42
9	WARRANTY AND SERVICE.....	44



Precautions for safe use

In order to use the equipment correctly and safely, please read the safety precautions carefully before using the equipment, and strictly observe the precautions.

Use of knowledge

- Please handle with care during transit or installation.
- Please ensure that the equipment is reliably grounded before use.
- The rated voltage used to connect AC distribution system must not exceed the allowable range of MPDU product identifier.
- Maximum load must not exceed MPDU rating.

Maintenance requirements

- Change the main control module and excellent series output module, and must be operated by professional and technical personnel.
- Because the MPDU output module base is strongly charged, in order to ensure personal safety, in the maintenance of equipment, please do a good job of insulation protection.
- Before disassembling the output module, please disconnect all outlet loads and prohibit replacing the output module with load.
- When installing the Outstanding Series output module, please pay attention to the direction of the module installation, do not reverse installation, to avoid damage to the product.

1 MPDU Introduction

MPDU (Module Power Distribution Unit) is the latest scientific achievements in the power distribution industry for data center. The originated Hot-Swap Control Module and field-replaceable Output Module design enable the user to upgrade the PDU to different product functional series (A, B, C, D series) and different product categories (MPDU, ZPDU) as well. Adopting overload and over-current hydraulic circuit breakers and energy-saving metal structure design, MPDU provides highly accurate and comprehensive energy metering of the connected devices in the data center cabinet. The MPDU is the innovative solution which meets requirements of Hot-Swappable, Sustainable, Upgrade-able and Maintainable for data center operation.

2 Scope of Application

2.1 MPDU can be applied to server rack, network cabinet and etc.

2.2 Outlet types (IEC320 C13, IEC320 C19, GB1002, GB2099.3, NEMA 5-15R, NEMA 5-20) and outlet quantity (8 outlets, 24 outlets, 36 outlets & 42 outlets) can be selected according to the actual needs.

2.3 MPDU complies with RoHS requirements. It is applicable for single phase 100~240VAC and three phase 200~400VA, output 32A, 63A, 3×16A, 3×32A, which can meet customers' requirements all over the world.

3 Terms & Definitions

3.1 Parameter and abbreviated units

Parameter	Definitions	Units of measurement
U	Input Voltage	V
I	Input load	A
P	Apparent Power	kVA
PF	Power factor	--
E	Power consumption	kWh
T1/T2	Temperature	℃
H1/H2	Humidity	%RH

3.2 MPDU is classificationed based on its function as below:

3.2.1 MPDU is divided into three series according to the product structure: excellence, overflight and beyond.

Main functions	Product Types		
	Excellent series (Modular)	Flyover series (integration)	transcendence series (Multi Standard)
Sheet metal shell	•	•	
Aluminum alloy housing			•
Main control module hot swap	•	•	•
Output module hot swap	•		
Fixed output socket system	•	•	
Multi mode output socket			•

Remark: • Means the specified function is supported

3.2.2 MPDU is organized into A, B, C, D 4 different series based on its function as below:

A Monitored PDU

B Per-port Monitored PDU

C Switched PDU

D Per-port Monitored & Switched PDU

Main functions	Product Series			
	A Series	B Series	C Series	D Series
Energy consumption monitoring of each phase	•	•	•	•
Input voltage monitoring of each phase	•	•	•	•
Input current monitoring of each phase	•	•	•	•
Apparent Power monitoring of each phase	•	•	•	•
Power factor monitoring of each phase	•	•	•	•
Temperature/Humidity monitoring	•	•	•	•
Current monitoring of individual outlet		•		•
Power monitoring of individual outlet		•		•
Energy consumption monitoring of individual outlet		•		•
On/Off status of individual outlet			•	•
Threshold settings of input voltage of each phase	•	•	•	•
Threshold settings of input current of each phase	•	•	•	•
Threshold settings of individual outlet		•		•
Outlet Switching			•	•

Power ON/OFF delay of individual outlet			•	•
---	--	--	---	---

Remark: • Means the specified function is supported

3.2.3 MPDU C/D series come with 2 options on the relay, monostable (normally open) relay and the latching relay;

Main functions	C/D series	
	Monostable Relay Type	Latching relay type
Sequential power on after power cycle	•	
Outlets remain current status when power switching supply fails		•

4 Main functions and Installation

4.1 Function description

4.1.1 Monitoring function: through the local LCD screen, user can view the current, voltage, energy consumption, power of each phase, baud rate, serial communication address, daisy chain address, device series, IP address, the current, power and power consumption of individual outlet (A&C series not included) and temperature, humidity status.

4.1.2 Outlet switching function (A&B series not included): switching On/Off each individual outlet, switching On/Off the breaker, set up the power on/off delay, Return-to-zero for power consumption at phase or individual outlet level.

4.1.3 Keep the former status (A&B series not included: keep the former state of each outlet after restart.

4.1.4 User-defined alarm: when thresholds of total current, individual current (A&C series not included) or temperature and humidity are exceeded

4.1.5 System default alarm: when the total rating current, individual rating current (A&C series not included) are exceeded or temperature and humidity threshold are exceeded.

4.1.6 Various alarm methods: Buzzer sounds, Alarm indicator flashes, value displayed in red from Web interface, the value flashes in red from LCD screen, alarm logs, E-mail notification and SNMP trap

4.1.7 User management: User permission configuration. (User can be set as administrator or normal user)

4.1.8 Access methods: Web Interface, Telnet command line, Modbus, SNMP (v1 / v2c / v3), Serial console,


4.1.9 LCD screen Energy-saving mode and mute-alarm-buzzer are supported.

4.1.10 Support multi-user operation system, Multi-browser compatible and remote software update.


MPDU A/B/C/D series function table

No.	Function	Description
1	Monitoring	Monitoring function: Through the local LCD screen user can view the current/voltage/energy consumption/power at input level or individual outlet level(A&C series not included), temperature/humidity status, band rate, serial communication address, device series, IP address.
2	Switching	Outlet switching function (A&B series not included): switching on/off each individual outlet or all outlets, set up the power on/off delay, reset power consumption at input or outlet level.
3	Keeping the former state	Keeping the former status (A&B series not included) :keep the former state of each outlet after restart
4	User-defined alarm	User-defined alarm: when thresholds of the input voltage, total current or individual current(A&C series not included), temperature and humidity are exceeded
5	System default alarm	System default alarm: when the total rating current, individual rating current(A&C series not included) or temperature/humidity threshold are exceeded

4.2.1 Vertical MPDU (0U)





Vertical Excellent series (Modular) Vertical Flyover series(integration) Vertical transcendence series (Multi Standard)



Excellent series (High-density; Modular) Excellent series (High-density; Modular)


4.2.2 Horizontal MPDU (1U)




1. Input power cord;
2. Hydraulic circuit breaker;
3. NMC Module;
4. LCD screen;
5. RUN:Operation indicator;
kWh:Energy pulse indicator;
ALM:Alarm indicator;
6. UP:Scroll up to the previous page;
7. DOWN:Scroll down to the next page;
8. CONTROL:Confirm and flip button;
9. RESET: Reset button;
10. NET: 10/100M Ethernet port;
11. SER: Serial port (MODBUS Supported);
12. IN: Daisy-Chain port;Connect to the OUT port of previous PDU;
13. OUT: Daisy-Chain port; Connect to the IN port of next PDU
14. T/H1:Temperature and humidity sensor port 1;
T/H2:Temperature and humidity sensor port 2;
15. Alarm:Audible and visual alarm port
16. Outlet LED indicator;
17. Output sockets;
18. Replaceable outlet modules;

4.3 Installation

4.3.1 Vertical-mounting (0U)



4.3.2 horizontal-mounting(1U)



5 Hardware instruction


5.1 MPDU module

Item	Function	Instruction
RUN	RUN indicator	Status: flashing every second
kWh	kWh indicator	Status: flashing frequency depends on the connected load
ALM	Alarm indicator	Status: flashing when threshold is exceeded.
NET	Ethernet port	LAN/WAN communication port
SER	Serial port	RS-485 Serial communication port
IN	Daisy-Chain port	Connect to the Out port of previous PDU
OUT	Daisy-Chain port	Connect to the IN port of next PDU
CONTROL	Control button	Press to view the Rack PDU status and configuration. Restore to factory settings: Press and hold the CONTROL button, then press RESET button to restore to factory settings
UP	Page UP	Scroll up to the previous page
DOWN	Page Down	Scroll down to the next page
RESET	RESET button	Restart system
LCD screen	View the data status	Display the power data and alarm status
T/H	Temperature/humidity sensor port	Connect to temperature/humidity sensors

5.2 System initialization


When power on the MPDU, boot animation starts, the buzzer sounds and RUN indicator flashes. It is going to be in normal working mode after that unit has initialized and the LCD has started displaying the power data.

5.2.1 Press the UP/DOWN button to view the Rack PDU information including the input voltage/ current/ power/power consumption of each phase, temperature/humidity status, baud rate, Modbus communication code, Daisy-chain code, IP address and device series.



5.2.2 Press the CONTROL button to view the current/power/power consumption of individual outlet (A&C series not included)

5.2.3 Press and hold the CONTROL button for 4 seconds to back to the input voltage/current/power/power consumption of each phase



5.3 Hardware Settings

5.3.1 Restore to factory settings:

Press and hold the CONTROL button to power on the MPDU at the same time (Or press and hold the CONTROL button and press RESET button at the same time) till the RUN indicator is flashing.

5.3.2 Buzzer mute button

Press and hold the CONTROL button for 4 seconds, then press the UP button within 1 second to enable or disable the alarm buzzer.


5.3.3 Address code settings

Turn to the Baud rate and Address code page by press the UP or DOWN button, then press and hold the CONTROL button for 4 seconds, When an “S” will be displayed in the upper right corner of the LCD screen, you can press the DOWN button to select the digit of the Modbus address and press UP button to set digit value from 0 to 9. Press CONTROL button to save the settings and PDU will restart.

5.4 Daisy-Chain

5.4.1 Ethernet Daisy-Chain

Support daisy-chain up to 4 PDUs (1 master and 3 slaves) so the user can manage multiple PDUs from one IP address through web interface. Daisy-chain schema is as following:



Ethernet Daisy-Chain settings:


- 1) Log in each MPDU, and configure the Work mode (Master unit or Slave unit) on Device Manage page.
- 2) Connect the NET port from the Master Unit to the WAN/LAN, other Daisy-chain cable connect the OUT port to the IN port of the next PDU. Connect all 3 Slave unit by the same way (see Figure above)
- 3) Access the Master through Web interface and check all the status of Slaves. If all are readable, daisy-chain is successful

Note: Only the same product series can support the Daisy-chain connection. Single phase and Three phase

or A/B/C/D series cannot Daisy-chain together. For example, A series MPDU with single phase input can be connected by A series with single phase only; D series MPDU with Three phase input can be connected by D series with Three phase input.


5.4.2 Star Connection

Support Star connection up to unlimited MPDU through a HUB. No limitation for the PDU quantity.



5.4.3 Serial Connection settings

The Modbus-RTU protocol is used here for the Star connection, The MODBUS Serial Server connect to the Bus arbiter, the RS485 port from the Bus arbiter connect to the SER port from each PDU. Serial connection can support up to 32 PDUs together. See figure as below.



Serial connection settings:


- 1) Log on to Web interface of each MPDU to configure the serial communication code from the Modbus address code on Device Manage page;

- 2) The Master unit collects the data from the SER port through the RS-485 serial communication cable.

Please refer to the 《MPDU MODBUS RTU Protocol Guide》 for details.

5.4.4 Serial Connection settings (Optional)

The Modbus-RTU protocol is used here for the Star connection, The MODBUS Serial Server connect to the IN port from the first MPDU. Daisy-chain cable connect the first MPDU OUT port to the IN port of the second MPDU. Connect all 32 Slave unit by the same way (see Figure above)Serial connection can support up to 32 PDUs together. See figure as below.




Serial connection settings:

- 1) Log on to Web interface of each MPDU to configure the serial communication code from the Modbus address code on Device Manage page;
- 2) The Slave1 unit collects the data from the IN port through the RS-485 serial communication cable.

Please refer to the 《MPDU MODBUS RTU Protocol Guide》 for details.

Note: The function is non-standard fitted, Pre-factory preset is required. as soon as Serial Connection settings is enable, “5.4.1 Ethernet Daisy-Chain” will not be available.


5.5 RJ45 terminal PIN instruction of RS485 port.



No.	Color	Instructions
1	Orange & White	GND
2	Orange	GND
3	Green & White	RS485-A
4	Blue	RS485-A
5	Blue & White	RS485-B
6	Green	RS485-B
7	Brown & White	+12VDC
8	Brown	+12VDC

5.6 Sensor Box (Optional)

MPDU could monitoring extend temperature, humidity, door status, smoke status, water status real time through external sensor box. Please refer to the 《Sensor Box Operating Manual》



Note: The function is non-standard fitted, Pre-factory preset is required. as soon as sensor box function is enable, “5.4.3 Serial Connection settings” will not be available.

6 MPDU Software introduction

6.1 Software overview

MPDU is equipped with embedded software system which provides lots of network services like WEB server, SNMP, Telnet, SMTP/SMTPS, MODBUS, NTP and etc. User can access MPDU through the Web Interface or other methods, at the same time it provides rich ports of secondary development and integration so the user can manage the device more easily.

6.2 Access method

Access through the Web Interface though IE browser (Supported web browsers includes Internet Explorer, Google chrome, Firefox and etc)

SNMP (V1/V2c/V3)

Command line interface (telnet)

Serial communication MODBUS RTU

6.2.1 Web interface

Open a browser and enter the default IP address (default IP address:192.168.1.163), the login window will pop up like below, See figure1-1.




Figure 1-1

Fill in the correct user name and password (Factory default login name is admin, password is admin) to login the main interface. The main interface is designed with three major screen sections shown in the following screenshot as figure 1-2

- 1) Device information: Selection of Master/Slave Unit , Software version, Daisy-chain address code, device type and device series
- 2) Navigation tab: shows function tabs available
- 3) Detail window: Shows PDU information under each function tab




Figure 1-2

A. Device Status: After enter Figure 1-2 you can view the monitoring information as below:

- 1) Input monitoring: The input current, voltage. Power, power consumption, power factor of each phase and On/Off status of circuit breaker.
- 2) Outlet Monitoring: The current, power, power consumption and ON/OFF status of individual outlet.
- 3) Environment monitoring: The Temperature/humidity status of 2 sensors.

B. Device Settings: Click the Settings tab to enter Figure 1-3 to configure thresholds of input voltage, input current, individual outlet current, temperature, humidity. And configure values for power On/Off delay of Individual outlet, power consumption return to zero and outlet switching.

- 1) Input threshold settings:
 - a. The input voltage threshold range: 0-250VAC
 - b. The input current threshold range: 0-63A for single phase, 0-32A for three phase
 - c. Temperature/Humidity threshold range: 0-40°C for temperature, 0-99% for humidity

MPDU

Device State Settings Device Network User Logs System

Settings

Total Threshold

Output Threshold

Energy Reset

Switch ON/OFF

Switch Group

Port Permissions

Master

Number	Name	Real Time Value	Min	Lower Limit	Upper Limit	Max	Save
1	L1 Current (A)	0.00	0	0	16	16	Save
2	L2 Current (A)	0.00	0	0	16	16	Save
3	L3 Current (A)	0.28	0	0	16	16	Save

Number	Name	Real Time Value	Min	Max	Save
1	L1 Voltage (V)	231.8	80	276	Save
2	L2 Voltage (V)	231.8	80	276	Save
3	L3 Voltage (V)	231.9	80	276	Save
4	Temperature 1 (°C)	NA	0	40	Save
5	Temperature 2 (°C)	NA	0	40	Save
6	Humidity 1 (%)	NA	0	99	Save
7	Humidity 2 (%)	NA	0	99	Save

Figure 1-3

2) Individual outlet threshold settings:

- a. The individual outlet current threshold range: 0-16A
- b. User-defined power On/Off delay for individual outlets or all outlets range: 0-10 seconds

Note: The low-load and overload threshold should be within the threshold range.

MPDU

Device State Settings Device Network User Logs System

Settings

Total Threshold

Output Threshold

Energy Reset

Switch ON/OFF

Switch Group

Port Permissions

Master

Number	Name	Real Time Value (A)	Min(A)	Lower Limit (A)	Upper Limit (A)	Max (A)	Delay (S)	Save
1	Output1	0.00	0	0	10	10	1	Save
2	Output2	0.00	0	0	10	10	1	Save
3	Output3	0.00	0	0	10	10	1	Save
4	Output4	0.00	0	0	10	10	1	Save
5	Output5	0.00	0	0	10	10	1	Save
6	Output6	0.00	0	0	10	10	1	Save
7	Output7	0.00	0	0	10	10	1	Save
8	Output8	0.00	0	0	10	10	1	Save
9	Output9	0.00	0	0	10	10	1	Save
10	Output10	0.00	0	0	10	10	1	Save
11	Output11	0.00	0	0	10	10	1	Save
12	Output12	0.00	0	0	10	10	1	Save
13	Output13	0.00	0	0	10	10	1	Save
14	Output14	0.00	0	0	10	10	1	Save
15	Output15	0.00	0	0	10	10	1	Save
16	Output16	0.00	0	0	10	10	1	Save
17	Output17	0.00	0	0	10	10	1	Save
18	Output18	0.00	0	0	10	10	1	Save
19	Output19	0.29	0	0	10	10	1	Save
20	Output20	0.00	0	0	10	10	1	Save
21	Output21	0.00	0	0	10	10	1	Save
22	Output22	0.00	0	0	10	10	1	Save
23	Output23	0.00	0	0	10	10	1	Save
24	Output24	0.00	0	0	10	10	1	Save

Figure 1-4

3) Power consumption Return-To-Zero

User can view the power consumption of individual outlet or each phase. The specified power consumption can be returned to zero by clicking the Reset button.

The power consumption value of specified outlet will be reduced from the total power consumption.

Number	Name	Energy (kWh)	Reset
1	L1	0	Reset
2	L2	3	Reset
3	L3	0.8	Reset

Number	Name	Energy (kWh)	Reset
1	Output1	0	Reset
2	Output2	0	Reset
3	Output3	0	Reset
4	Output4	0	Reset
5	Output5	0	Reset
6	Output6	0	Reset
7	Output7	0	Reset
8	Output8	0	Reset
9	Output9	0	Reset
10	Output10	0	Reset
11	Output11	0	Reset
12	Output12	0	Reset
13	Output13	0	Reset
14	Output14	0	Reset
15	Output15	3	Reset
16	Output16	0	Reset
17	Output17	0	Reset
18	Output18	0.6	Reset
19	Output19	0	Reset
20	Output20	0	Reset
21	Output21	0.2	Reset
22	Output22	0	Reset
23	Output23	0	Reset
24	Output24	0	Reset

Figure 1-5

4) Outlet Control

- Click the ON/OFF button after the outlet to switch ON/OFF the specified individual outlets;
- Click the ON/OFF button after each phase to switch ON/OFF the outlets from the specified phase;
- Click All ON/All OFF button to switch ON/OFF all outlets at the same time.




Figure 1-6

5) Switch Group

- Tick off the box from the Outlet Groups listed;
- Select Enable from the dropdown list and click Save button;
- By clicking the ON or OFF button, you can switch on/off the outlets this outlet group at one time;




Figure 1-7

6) Port permissions settings:

Modify the port permissions: In the user name drop-down list, select the administrator or normal user account. Next to the corresponding output bit name, click the ☒ symbol to have the output bit control permission, and the unsigned symbol is no output bit control permission.

Depending on the selected user, you can edit the output rights of multiple users and click the "Save" button.




Figure 1-8

C. Device Management

Device Settings: To configure the device name, LCD screen energy-saving mode, mute the buzzer alarm, Work mode, Modbus address code and baud rate.




Figure 1-9

D. Network Settings:

1) HTTP/SSL settings

Set-up and save the HTTP/SSL port according to the working mode.

The default port is 80 under normal work mode,

HTTPS(SSL) Mode Port is 443 by default

Note: These settings will take effect when MPDU is restarted

2) Network settings and modify IP address, for example:

IP address:192.168.1.163 (factory default IP) ;

Subnet mask:255.255.255.0

Gateway:192.168.1.1

DNS address:202.96.128.86 by default;Please enter a correct DNS address in order to send the E-mail




Figure 1-10

3) DHCP settings:

The default state of DHCP setting is Off. User can select On from the DHCP drop-down list and click Save to enable it. After restarting the software, device will get the IP automatically. IP can be viewed from the LCD screen.




Figure 1-11

Remark: When DHCP is On, the device automatically obtains the router to assign an IP address and will not allow you to manually modify the network settings.

4) SNMP settings

a. SNMP V1/V2c settings:

User can decide to Enable or Disable the SNMP access from the Web Interface.

Enable SNMP V1 and V2c requires configuration of read community and write community. And the default “Read community” and “Write community” is public and private respectively.

Trap address: can set 2 trap addresses. Fill in the trap address of SNMP management platform, Trap information will be sent directly to the addresses.

b. SNMP v3 Settings:

Select “On” and fill in account, password, private key.

Note: After save of the SNMP setting, software must be restarted.




Figure 1-12

- 5) SMTP settings: Click SMTP from the network navigation tab to enter the SMTP setting as figure 1-12

Fill in the parameters of SMTP service including SMTP account, password, SMTP server, working mode (SMTP/SMTPS) and e-mail recipients (up to 5 recipients), then Click Save. SMTP settings will take effect when MPDU is restarted.

SMTP test: fill in the recipients address and click “Test” SMTP setting is successful if test email was received. If not received, please double check and configure the SMTP again.

The screenshot shows the MPDU web interface with the 'Mail System Settings' page selected. The left sidebar lists network-related settings: HTTP, DHCP, SNMP, SMTP, Telnet, NTP, and ModbusTCP. The main content area contains the following fields and controls:

- Mail Sending Account:
- Mail Sending Password:
- Mail Sending Server Address:
- Mail Receiving Users List:
- Mail Receiving Account:
- SMTP Port:
- SMTPS Port:
- Work Mode:

At the bottom of the settings area, there are four buttons: Test, Delete, Add, and Modify.

Figure 1-13

6) Telnet Settings

Telnet: select “Enable” or “Disable” (Enable by default) and save, make sure to restart the software after modification. Telnet account and password is the same one used for login. Telnet port is 23

The screenshot shows the MPDU web interface with the 'Telnet Settings' page selected. The left sidebar lists network-related settings: HTTP, DHCP, SNMP, SMTP, Telnet, NTP, and ModbusTCP. The main content area contains the following fields and controls:

- Username:
- Password:
- Telnet Port:
- Telnet:

At the bottom of the settings area, there is a Save button.

Figure 1-14

Note: telnet settings will take effect when MPDU is restarted.

7) NTP Settings:

NTP section displays the device current time which is also the time recorded for the logs.




Figure 1-15

a. Local time calibration

Click Time Acquisition to synchronize the MPDU system time to the local machine.

b. Network time calibration

Click Time Acquisition to synchronize the MPDU system time and date to the specified time zone according to the NTP server.

Note: Please make sure the MPDU is connected to the internet when synchronize the system time

8) Modbus-TCP Settings

Modbus-TCP: select “On” or “Off” (Off by default) and save, make sure to restart the software after

Modbus-TCP port is 502, Modbus-TCP address code is 1.




Figure 1-16

Note: Modbus-TCP settings will take effect when MPDU is restarted.

E. User Settings

- a. Create new account: Click User Settings tab and fill in the user name, password, confirm password, then click Add to create new user account.

Remark: The maximum length for user name and passwords is 10 characters, the user name and password exceeds the maximum of 10 characters will be a failure action.

- b. Edit user account: Click User settings, fill in the new user name, password and confirm-password in the right side of the existing User name and Password, then click Save.
- c. Delete User account: Select the user account from the user list and click Delete.

Remark: The default Administrator cannot be deleted. The default user Admin can't be deleted.

- d. Permission settings: Click permission setting and select the Administrator or normal user from the drop-down list, then click Save button. See figure 1-17

Remark: Normal user doesn't have the permission to do the configuration (Save/configure/delete button will not be available), only the administrator have the full permission to do so.




Figure 1-17

F. Logs

Log type: Alarm log and operation log

Log information: time, log type and detail information

Memory capacity: Max 300 logs, the initial logs will be removed when reached 300 logs.

To view the logs: Click a page number to open a specific page of the log

Every page display 30 logs and maximum support to 10 pages; the initial pages will be deleted when over 10 pages

To delete the log: Click Delete on the web page, at the prompt, check OK to delete all the logs.

To export the log: The logs from the current page can be exported via log.xls format through IE/Google/Firefox browser.

Time	Type	Description
13-02-2019 13:17:16	Alarm Release	Circuit Breaker 3 Closed, Cut-out time period : 13-02-2019 13:17:14 To 13-02-2019 13:17:16
13-02-2019 13:17:16	Alarm Release	L3 Real Time Value: 229.6 V; Min: 80 V; Max: 276 V, Alarm time period : 13-02-2019 13:17:12 To 13-02-2019 13:17:16
13-02-2019 13:17:14	Alarm	Circuit Breaker 3 Open
13-02-2019 13:17:12	Alarm	L3 Real Time Value: 0 V; Min: 80 V; Max: 276 V

Page: 1 To 1 Go Previous page Next page Total : 4 Export Delete

Figure 1-18

Note: At the prompt of “Sever object cannot be built”, please try again after configuring the security level of IE browser following the below steps:

The internet Explorer goes to: Tools-- Internet Options-- Security- Custom Level-- Tick off Enable(unsafe) from Initialize and script ActiveX controls not marked as safe for scripting--- OK-- OK

G. System command settings:

To Restart or Restore to factory settings from the system command drop-down list.




Figure 1-19

6.2.2 SNMP access


This software support SNMP V1, V2C and V3, a MIB file can be provided at customer's request. User can view the power information and environment status and receive the alarming from the device.

After enable the SNMP function from Web Interface, A SNMP management software is required to be installed.

Please refer to protocol instruction for the OID information of the SNMP

6.2.3 Telnet Command Line Interface

User can use the Telnet command line interface to view, configure and manage the Rack PDU remotely and easily. Telnet does not support the Daisy-chain connection, user can only access and manage the Master unit.

6.2.3.1 To open the Telnet client  by Start→ Run command→ enter “Telnet” in the input box and click OK

6.2.3.2 Enter the IP address as illustrated in figure 2-1




Figure 2-1

Press ENTER. At the prompts, enter your user name and password to log in to the command line interface as figure 2-2





Figure 2-2

A. "PHASE" command

Use the PHASE command to view the power data including current, voltage, power, power factor, power consumption on each phase

Command line format: PHASE as figure 2-3



```
192.168.1.163 - PuTTY
Welcome To MPDU Telnet Server!
User: admin
Password: *****
Command: PHASE  OUTPUT SENSOR ON OFF REBOOT RESET QUIT HELP

Command: phase

Name          L1          C1          C2
Voltage:      220V(170--275)  220V(170--275)  220V(170--275)
Current:      3.5A(0--16)    0.4A(0--8)     3.1A(0--8)
Power:        0.738 kW      0.054 kW       0.684 kW
PF:           0.95         0.61           0.99
Energy:       1.8 kWh      0.1 kWh        1.7 kWh


Command: █
```

Figure 2-3

B. “OUTPUT” command

Use the OUTPUT command to view the current, power, power consumption and ON/OFF status at individual outlet level.

Command line format: OUTPUT; See figure as 2-4



```

Command:output
Output1: 0.0 A(0--10) 0.0 kVA 0.0 Kwh Status:ON
Output2: 0.0 A(0--10) 0.0 kVA 0.0 Kwh Status:ON
Output3: 0.0 A(0--10) 0.0 kVA 0.0 Kwh Status:ON
Output4: 0.0 A(0--10) 0.0 kVA 0.0 Kwh Status:ON
Output5: 0.0 A(0--10) 0.0 kVA 0.0 Kwh Status:ON
Output6: 0.0 A(0--10) 0.0 kVA 0.8 Kwh Status:ON
Output7: 0.0 A(0--10) 0.0 kVA 0.8 Kwh Status:ON
Output8: 0.0 A(0--10) 0.0 kVA 0.0 Kwh Status:ON
Output9: 0.0 A(0--10) 0.0 kVA 0.1 Kwh Status:ON
Output10: 0.0 A(0--10) 0.0 kVA 0.1 Kwh Status:ON
Output11: 0.0 A(0--10) 0.0 kVA 0.0 Kwh Status:ON
Output12: 0.0 A(0--10) 0.0 kVA 0.3 Kwh Status:ON
Output13: 0.0 A(0--10) 0.0 kVA 0.0 Kwh Status:ON
Output14: 0.0 A(0--10) 0.0 kVA 0.0 Kwh Status:ON
Output15: 0.0 A(0--10) 0.0 kVA 0.0 Kwh Status:ON
Output16: 0.0 A(0--10) 0.0 kVA 0.0 Kwh Status:ON
Output17: 0.0 A(0--10) 0.0 kVA 0.0 Kwh Status:ON
Output18: 0.0 A(0--10) 0.0 kVA 0.0 Kwh Status:ON
Output19: 0.0 A(0--10) 0.0 kVA 0.0 Kwh Status:ON
Output20: 0.0 A(0--10) 0.0 kVA 0.0 Kwh Status:ON
Output21: 0.0 A(0--10) 0.0 kVA 0.0 Kwh Status:ON
Output22: 0.0 A(0--10) 0.0 kVA 0.0 Kwh Status:ON
Output23: 0.0 A(0--10) 0.0 kVA 0.0 Kwh Status:ON
Output24: 0.0 A(0--10) 0.0 kVA 0.0 Kwh Status:ON
Command:


```

Figure 2-4

C. “SENSOR” command

Use the Sensor command to view the temperature/humidity status and its threshold

Command line format: SENSOR; see figure as 2-5



```

Command:sensor
Temperature1: 26 C(0--85) Humidity:25%(0--90)
Temperature2: 27 C(0--60) Humidity:28%(0--99)
Command:

```

Figure 2-5

D. “ON/OFF” command

Use the ON/OFF command to switch On/Off the individual outlet, outlets from each phase or all outlets.

Command line format: ON/OFF **【index】** **【operation】** see as figure 2-6

【index】 Individual outlets, Group, Phase.

【operation】 Serial number 1 means the outlet 1 from phase 1, see details as below:





Figure 2-6

【index】	Description
OUTPUT	<div>A screenshot of a PuTTY terminal window titled "192.168.1.163 - PuTTY". The terminal shows the following text: "Command:ON", "on output [operation]", "operation:'1' is the output1 switch...", "on group [operation]", "operation:'1' is the group1 switch...", "on phase all", "Command:ON OUTPUT 1", and "Command successfully!".</div> <p>Enter command line: ON OUTPUT 1 to switch on the outlet 1;</p> <p>Enter command line: OFF OUTPUT 1 to switch Off the outlet 1;</p> <p>OUTPUT command can switch ON/OFF only one outlet at one time.</p>
GROUP	<div>A screenshot of a PuTTY terminal window titled "192.168.1.163 - PuTTY". The terminal shows the following text: "Command:on", "on output [operation]", "operation:'1' is the output1 switch...", "on group [operation]", "operation:'1' is the group1 switch...", "on phase all", "Command:on output 1", "Command successfully!", "Command:on group 1", "Command successfully!", and "Command:" followed by a green cursor.</div> <p>Enter command line: on group 1 to switch on outlet from branch circuit 1;</p> <p>Enter command line: off group 1 to switch off outlet from branch circuit 1;</p>

PHASE	 <p>Enter command line: on phase 1 to switch on outlets from phase 1;</p> <p>Enter command line: off phase 1 to switch off outlets from phase 1;</p>
-------	--

E. REBOOT Command

Use the REBOOT command to restart the device as figure 2-8




Figure 2-8

F. RESET Command

Use the RESET command to restore to factory settings as figure 2-9



Figure 2-9

G. QUIT Command

Use the QUIT command to logout the current Telnet command line interface. See figure 2-10




Figure 2-10

H. Help Command

Use the HELP command to shows general help, see figure 2-11




Figure 2-11

6.2.4 MODBUS-RTU access

MODBUS-RTU access use two-wire RS-485 serial communication port for serial access, please refer to the

《MPDU MODBUS RTU Protocol Instruction》 for the MODBUS access

Modbus-RTU protocol configuration including Modbus -RTU communication address (1-99), baud rate(4800, 9200, 19200, 38400, 115200), data bit (8) , parity (no) , stop bit (1)

Note: The serial communication data is collected from the SER port of PDU. Please refer to the 《MPDU MODBUS RTU Protocol Instruction》 for details.

7 Frequently Asked Questions (FAQs)

7.1 Q: Forget IP address?

A: check on the LCD screen, the first page displays the IP address.

7.2 Q: Failed to login?

A:

7.2.1 Connect the MPDU to the PC directly, change the network setting of the PC and make sure the MPDU and PC are in the same network segment, the default IP address of the MPDU is 192.168.1.163, Subnet mask: 255.255.255.0, gateway: 192.168.1.1, so the PC network will be like following: IP address 192.168.1.2, Subnet mask: 255.255.255.0, gateway: 192.168.1.1

7.2.2 Open a browser and enter the IP address and login to the Web interface with user name and password;

7.2.3 Click Network Setting from the web interface and change the IP address of the MPDU and make sure the address is in the same network segment of the PC.

7.2.4 Recover your network setting of PC and use the new IP address of the MPDU to login.

7.3 Q: Fail to send email notification?

A:

7.2.1 Check the network connection and make sure the network is connected.

7.2.2 Check DNS configuration and confirm whether it is successful.

7.2.3 Check and confirm the SMTP sever is correct and the same as the sender mailbox sever. Please make sure SMTP port is correct.

7.2.4 Make sure the recipients address is correct.

7.4 Q: How to restore to factory settings?

A: Press and hold the CONTROL button to Switch on the MPDU (Or press the CONTROL button and RESET button together), till the RUN indicator is flashing.

8 Technical Parameters

No.	Performance parameter		Technical parameter
1	Input	Rated input voltage	Single phase:100VAC~240VAC Frequency: 50~60Hz; Three phase:200VAC~400VAC Frequency: 50~60Hz;
		Input plug	Standard IEC industry plug or connector
		Power cord	32A:3×6mm ² 63A:3×16mm ² ; 3×16A:5×2.5mm ² 3×32A:5×6.0mm ²
		Cable length	3M
		Max. load current	Single phase: 32A, 63A Three phase: 3×16A, 3×32A
		Overload protection	16A/32A hydraulic breaker
2	Output	Socket standard	IEC320 C13, C19 GB1002, GB2099.3 NEMA 5-15R, NAMA 5-20R
		Socket quantity	8/24 / 36/42outlets;
		Output voltage	Single phase:100VAC~240VAC Frequency:50~60Hz;
		Max output current	Single phase:32A, 63A
		Max phase current	16A, 32A
3	Control ports	NET port	1×RJ45 port
		Daisy chain port	2×RJ45 port
		SER port	1×RJ45 port
		Temperature & humidity port	2×RJ11 ports
		Audible and visual alarm port	1×RJ11 ports
4	Display	Working state	1×LED
		Power pulse	1×LED

		Alarm	1×LED
		IP Address, MPDU state, measurement value, alarm state	0U: 2.8 inch TFT screen 1U: 1.44 inch TFT screen
5	Load current display	Total current	Full-scale:16A/32A, Accuracy:±1%rdg.±10dgt. Resolution:0.01A, Response:500ms
		Individual load current	Full-scale:10A/16A, Accuracy:±1%rdg.±10dgt. resolution:0.01A, Response:500ms
6	Accuracy of Temperature/humidity sensor	Temperature	Working rang: 0℃ ~ +45℃ Accuracy:±1℃ , Response: 400ms
		Humidity	Working rang: 10-90% Accuracy:±5%RH, Response: 400ms
7	Product size	(L×W×D)	Vertical produt: Excellence, flying series: 1829*56*52mm (24 bits) 1829*56*62mm (36/42 bits) Beyond series: X*66.6*44.4mm, X length depending on the number of socket outlets. Horizontal produt:482.4×216×44.4mm (8 bits)
		Mounting option	Excellent, flying series: behind the nail installation, installation hole center distance 1555.75mm Beyond the series: hanging ear installation, fine adjustment, specific length depends on the number of sockets.
8	Case color	Color	Black
9	Standard accessories	Installation bracket	1 set
		Network connection cable	2M, Blue
		Serial connection cable	2M, Ivory white
		User manual	1 set (CD)
10	Optional accessories	Sensor	Temperature/humidity sensor

11	Environment	Working	0℃ ~+45℃
		Environment	Relative humidity: 5% ~95%
		Storage	Temperature: -20℃ ~+70℃
		Environment	Relative humidity :5% ~95%
12	ROHS	Compliance	

9 Warranty and Service

The product is guaranteed for two years from the date of purchase. We will repair or replace the defective products covered by this warranty. If product has already exceeded the warranty period or the problem are caused because of illegal operation, a corresponding fee will be charged.

9.1 The below cases are not covered by the warranty:

9.1.1. Problem caused because of improper maintenance

9.1.2. Problem caused because of unauthorized change, modify or improper use

9.1.3. The device are not used in the stipulate physical environment

9.1.4. Problem in consequence of any Force Majeure incidents

9.2 Repair notice:

9.2.1. Please make sure to use protective hard carton when arrange the shipment to repair, the problem occurred during the shipment is not covered by the warranty.

9.2.2. Please make a short note about the problem and the operation process

9.2.3. Please pay for the shipping cost as well as the customs duty

9.2.4. Please list your name, address as well as phone number that we can contact you at any time.